

Pt-100 temperature sensor Connection scheme

Particulars, Advanced Measurement System Ltd.

Pt-100

- ❑ Connector – 4 pole Lemo connector (included).
- ❑ Should be wired according to the scheme. Compatible to almost all temperature controllers with Pt-100 input

Sensor at the
mounting table

Chassis mount
connector



Connector – should be
wired according to the
input of the temperature
controller.